



Weathertight Windows & Doors Ltd
Unit 8, Strathallan Estate,
4 Strathallan Street,
PO Box 2455
Dunedin

(p) 03 455 5501
(m) 021 242 2088

Dave's installation notes:

Lug Fixed:

Fit fixing lugs as directed in following drawings (don't need as many as specified)
We screw them into the frames (screws supplied)

Direct Fixed:

Drill as many fixing points as required for fixing lugs
Try to drill as few as possible in the sills, and ensure that any that are, are sealed over

All doors require direct fixing (particularly French doors) either instead of or as well as fixing lugs
This is extremely important, fixing lugs are not enough to support the weight of the doors
The door should have 8mm cover over the frame. French doors should have 4mm gab between door leaves

Packing – Pack behind frame at each fixing point so unit is level & plumb (or whatever suits)
Ensure packers extend behind frame, particularly on the sill to support the weight

Reveals – If reveals are to be fitted after installation it is very important to make sure the frame is an equal distance in from the interior lining otherwise reveals will have to be planed to suit. With hinged doors this may not be possible since they have to be installed plumb

Glazing - Heel & toe all doors & windows (even awning windows)

Pack doors beside locks & strikers to ensure jambs are straight (or locks may not engage properly)

Pack heads of long windows to stop sagging (when installed with fixing lugs only)

Packers are blue first, then yellow (sometimes white)

Use glass cleaner or detergent to lubricate beads before knocking on, very important

Always put 2 shortest beads on first, gently tap on with a rubber hammer or not so gently but not hard enough to split the welds

Good luck any questions ring work 034555501
Me 0212422033
Paul 0212138004